# CI-200 SERIES

Weighing Indicator



OWNER'S MANUAL



# **Cautions for Your Safety**

Please comply with 'Cautions for Your Safety', which will lead you to use the product safely and properly to prevent any dangerous situations.

- $\,\blacksquare\,$  Cautions are divided into 'Warning' and 'Alert', which mean as follows.
- Keep this manual in a place where product users can find out, after finish reading it.





Never disassemble, repair or retrofit the product.  It might exclude the product from the quality assurance and cause the damage to devices, electric shock or fire.	Ensure the power plug to be fully inserted to prevent shaking.  Any instable connection might cause electric sparks to set fire.	Ensure the grounding of the product.  Poor grounding might cause failure or electric shock upon electric leak.
Do not damage, process, excessively jerk, bend or twist the power cord. It might damage the power cord to cause fire or electric shock.	Keep any combustible spray or fire source away. It might cause fire.	Do not spray water to the outside of the product or use it in any humid place. It might deteriorate the insulation of electric parts that can cause the electric shock, fire risk or weighing errors.
Do not place the product to the direct sunlight or near any hot object like a heater. It might cause fire.		



Check the weighing error anytime for the accurate weighing.

Any use out of the allowed tolerance for the careless use or other causes might not ensure the accurate weighing.

Customer Service: 080-022-0022

Do not use the product at a place with sudden temperature changes or severe vibrations.

It might cause the weighing error or failure.

Avoid any sudden shock to the product. It might damage the product to fail the accurate weighing.

Find a proper place to attach the rubber pad at the bottom of the indicator, which was shipped together.

Find a proper place to attach the rubber pad at the bottom of the indicator, which was shipped together.

# Contents

1. Features	9
1-1. Features	9
1-2. Major Functions	9
1-3. Analog and A/D Conversion	
1-4. Digital and Display	10
1-5. General Specifications	11
1-6. Communication and Option	11
2. Specifications in Appearance	12
2-1. External Dimension	12
2-2. Front Panel Descriptions	14
2-3. Rear Panel Descriptions	20
3. How to Install	22
3-1. How to Connect Load Cell	22
4. Weight Setup Mode	23
4-1. Weight Setup Menu	
4-2. How to Seal the Indicator	
5. Set Mode	31
5-1. How to Enter the Set Mode	
5-2. Descriptions on key operations in the Set Mode	
5-3. Set Menu Descriptions (F00 ~ F82)	
5-3-1. General Function	35
5-3-2. RS-232 (Serial Communication) Function	41
5-3-3. Print Function	46
5-3-4. Checker Function	51
5-3-5. Other Functions	52
6. Test Mode	53
6-1. How to Enter the Test Mode	
6-2. Test Menu	53

<b>7. System Mode</b>	58
7-1. How to Enter the System Mode	
7-2. PCS Mode	60
7-3. Percent Mode	62
8. General Function Descriptions	64
8-1. Item Number Input Method	64
8-2. Key Tare Input Method	64
8-3. How to Check Subtotal, Total and Weighing Count	65
8-4. How to Enter High Limit	66
8-5. How to Enter Low Limit	66
9. Weighing Mode	67
9-1. Zeroing Function – LED	
9-2. Tare Function – LED	
9-3. Hold Function – LED	68
9-4. Zeroing Function – LCD	69
9-5. Tare Function – LCD	69
9-6. Hold Function – LCD	70
10. Charge and Use Time	71
10-1. How to Use and Charge the Chargeable Batter	71
10-2. Use Time of the Battery	71
11. RS-232C Interface in Detail	72
11-1. RS-232C Port Connection	72
11-2. How to Connect Serial Communication Devices	73
11-2-1. How to Connect an Auxiliary Display	73
11-2-2. How to Connect a Label Printer	
11-3. RS-232 Communication Protocol	
11-3-1. 22 Bytes for CAS	73
11-3-2. 10 Bytes for CAS	74
11-3-3. A18 Bytes for AND	74
12. Error Message	76
12-1. Error Message from the Weight Setup Mode	
12-2. Error Message from the Weighing Mode	

## **Preface**

Thank you very much for purchasing CAS International Indicator.

This produce is characterized by the excellent performance and luxurious features through strict examinations, as well as elaboration for each part under our strict quality control.

CA Indicator (CI series) is a product with rich functions and various external interfaces, which is designed to comply well with special requirements in a variety of industrial fields under strong and beautiful designs in appearance.

In addition, it is designed for the user-friendly programs for the easier use of indicator by any user with the built-in message display functions to help users understand the product.

Please use the product right and sufficiently utilize functions of CI-200 series as you read this manual thoroughly before using CI-200 series.

# 1. Features

#### 1-1. Features

☐ Suitable for the platform and bench type scale and weighing system
☐ Easy operations
☐ Simple and prompt full digital calibration (automatic weight setup at once)
☐ Weight backup functions [restoring weight at the power supply On/Off]
☐ Multiple weights setup functions [5 point input weight setup]
☐ Command mode functions [PC control functions - data request and setup]
☐ 6 line [basic] / 4 line load cell Input
☐ Front panel key lock
☐ User message output functions
☐ High & low limit, zero, OK signal output functions (only for LCD, SC)
☐ System functions [count, percent, summation] (only for LCD)
☐ Tare input functions using key
☐ Gravity calibration functions

# 1-2. Major Functions

☐ Various printer connection supports [roll DEP & label DLP printer]
☐ Free to set the maximum weight and a division value as a user desires
☐ Independent zeroing functions
☐ Built-in hardware test functions

## 1-3. Analog and A/D Conversion

Applied voltage for load cell	DC 5V (350Ω maximum 8 possible connections)
Zeroing range	0 ~ 2mV/V
Input sensitivity	0.5 uV / D (OIML, )Ntep, KS
input sensitivity	0.5 uV / D (Non OIML, )Ntep, KS
Non-straightness	0.01% Full Scale
A/D internal resolution	1/520,000
	1 / 10,000 (NTEP, )OIML, KS
A/D external resolution	1/20,000 (Non NTEP, )OIML, KS (Possible with the use of sufficient output at 2mV/V L/C)
A/D conversion speed	Maximum 80 rounds/second
Weight setup	Full Digital Calibration: SPACTM (Automatic weight setup at once)

**1-4. Digital and Display** \* Communication (RS 232/422) ensures the free setup of independent use.

Communication (RS 232/122) Ci	sares the nee setup of mae	perident diser
Weight display	CI-200A, CI-200S, CI-200SC	LED (6 digit)
	CI-201A	LCD (6 digit + Sign)
Character size	CI-200A	25 mm (Height)
Character size	CI-201A	24 mm (height)
Sign below zero point	"-" minus sign	
Sign for status	ZERO, TARE, NET, STABI UNIT(kg)	E, HOLD,

# 1-5. General Specifications


AC Adapter		AC 100-240 V (DC 12V, 1.25A)
Operating tempera	ture	-10℃ ~40℃
Product size	CI-200A CI-201A	139mm(H) x 206mm(L) x 91.05mm(W)
Froduct size	CI-200S CI-200SC	169.5mm(H) x 250mm(L) x 83mm(W)
Product weight	CI-200A CI-201A	About 1.3kg
Froduct weight	CI-200S CI-200SC	About 1.5kg

# 1-6. Communication and Option

Basic	COM1 (RS-232 Printer & PC Interface )
Optional	COM2 (RS-232 Printer & Auxiliary Display)
Ориона	RS-485 Multi Drop Interface


<sup>\*</sup> COM2 can be selectively used for a printer (RS-232).


# 2. Specifications in Appearance







(DESK TYPE)







(WALL MOUNT TYPE)







# (CI-200S, CI-200SC)





(DESK TYPE)





(WALL MOUNT TYPE)

#### 2-2. Front Panel Descriptions

CI-200A



#### CI-201A



# (1) Main Display (Weight Display) A. Displaying the value of gross or net weight.

- B. Displaying error messages for any abnormal motion or weigh setup error/
  C. Displaying the status value for the Set Mode and weight setup mode.

## (2) Status Display (Lamp)

LED Lamp	LCD Stat	tus Display	Descriptions
Stable	0		The weighed weight is stable.
Net weight	NET		The current display of weight is a net weight.
Zero point	->0≪-		The current weight is 0 kg.
Hold	HOLD		The current status is under hold.
			Displayed when the battery should be charged (chargeable battery).
-	HI	High limit	The weight is heavier than the upper limit.
-	LO	Low limit	The display of lower limit is lit if the value set at F50 is smaller than the lower limit, or greater than the lower limit or smaller than the upper limit.
-	0K	Normal	The weight is greater than the lower limit and smaller than the upper limit.
Tare	◁		The current status is at the tare status.
Communicat ion	٥		The current status is at the communication status.
-	SUM	Summatio n lamp	The current weight is the value of summation.
-	PCS	Quantity lamp	The current mode is at the count mode.
-	%	Percent lamp	The current mode is at the percent mode.





# (1) Main Display (Weight Display) A. Displaying the value of gross or net weight. B. Displaying error messages for any abnormal motion or weigh setup error/ C. Displaying the status value for the Set Mode and weight setup mode.

## (2) Status Display (Lamp)

Stable	The weighed weight is stable.
Tare	The current status is at the tare status.
Net weight	The currently displayed weight is a net weight.
Hold	The current status is under hold.
Zero point	The current weight is 0 kg.
Communication	The current status is at the communication status.
Kg	The current weight unit is set to kg.
lb	The current weight unit is set to lb.
Lack	The weight is less than the setup value. (SC Only)
Fixed Quantity	The weight is within the setup range. (SC Only)
Excess	The weight is greater than the setup value. (SC Only)

# (3) Keyboard

Function Key
--------------

F1	* Some functions can be defined to the needs.  (The function set at F17 in the Set Mode will be operated.)
F2	* Some functions can be defined to the needs.  (The function set at F18 in the Set Mode will be operated.)

Number Key	
1 zero	* It enters 1 in the input mode.  * It sets the weight display near zero point to 0.
ZERO	(Arange of 2%, 5%, 10%, 20% and 100% can be selected.)
	*Long press to enter the test mode.
<b>2</b> G/N	* It enters 2 in the input mode.  * Each press after setting up the tare displays the gross weight and the net weight in turn.  (The displayed weight is the net weight when the net weight lamp is on, but the displayed weight is the gross weight when the net
	weight lamp is off.)  * Long press to enter the setup mode.
3 TARE	* It enters 3 in the input mode.  * Use it to weigh with the tare.  * The current weight is memorized as the tare by pressing the key.  * Press the key when the load tray is empty to release the tare.  * Long press to enter the system selection mode.  (CI-201A Only)
4 I*SUM	* It enters 4 in the input mode.  * Use it to check the subtotal (partial summation).  * Long press to enter the system weight setup mode.  (CI-201A Only)
<b>5</b> g*sum	* It enters 5 in the input mode.  * Use it to check the grand total (entire summation).
6w*cnt	* It enters 6 in the input mode.  * Use it to check the weighing count.
<b>7</b> PRINT	* It enters 7 in the input mode.  * Use it for the manual print. (manual print key)  (Print format can be changed in the Set Mode.)

8 HOLD	* It enters 8 in the input mode.  * Use it to fix the shaking weight.		
9в*СНК	* It enters 9 in the input mode.  * Use it to check the remaining capacity of battery.		
CLEAR	* Use it to correct any wrong input while entering data.  * Use it to enter a decimal point (.) in the weight setup mode and weighing mode.		
<b>O</b> ITEM	* It enters 0 in the input mode.  * Use it to register an item number. (0 ~ 19)		
SET	Use it to save the current status and exit from the weight setup mode, Set Mode and test mode.      Use it to check the current weight value in PCS and percent mode. (CI-201A Only)		

#### Double Key

4 i-sum	* Use it to print the subtotal.
5 <sub>G*SUM</sub> 7PRINT	* Use it to print the grand total.
SET + 3 TARE	* Use it for the tare key.  * If the tare is known, enter it using the numeric keys.  (If the remaining value occurs when the input value is divided into the minimum unit, the value is rounded and entered.)  The key tare function cannot be used during the PCS and percent functioning.


# 2-3. Rear Panel Descriptions

## CI-200A, CI-201A



• SEALING (CAL S/W)	Use it to set the weight (calibration).		
• POWER	* Use it for the power supply.		
• LOAD CELL	A port to connect load cell.		
• RS-232C	Serial Com 1 and Com 2 port (connect PC or printer)		
• F/G	It is a terminal for grounding to improve electric noises, which is connected to the grounding line upon any abnormalities in the product. (If the grounding terminal of the product is not connected, it might cause failures.)		

## CI-200S, CI-200SC




• SEALING (CAL S/W)	Use it to set the weight (calibration).		
• POWER	* Use it for the power supply.		
• LOAD CELL	A port to connect load cell.		
• RS-232C	Serial Com 1 and Com 2 port (connect PC or printer)		
• F/G	It is a terminal for grounding to improve electric noises, which is connected to the grounding line upon any abnormalities in the product. (If the grounding terminal of the product is not connected, it might cause failures.)		

#### 3. How to Install

#### 3-1. How to Connect Load Cell

Connect the load cell connector to the load cell port on the back of the indicator.

\* How to connect the load cell to the connector.



Pin Number	Pin Function
1	EXC+
6	SEN+
2	EXC-
7	SEN-
3	SIG+
4	SIG-
5	SHIELD

Note 1. When 4 line load cell is used, connect EXC+ and SEN+ to '+' power supply terminal in the load cell input, and connect EXC- and SEN- to '-' power supply terminal in the load cell input.

\* Relationship between the load cell output and input sensitivity.

The input sensitivity of this product is maximum 0.2uV/digit or more.

The following equation should be satisfied upon the system design.

Example 1) Number of load cell: 4 ea

Rated capacity of load cell: 500 Kg Rated output of load cell: 2mV/V

Value of a division: 0.10 Kg

Applied voltage of load cell: 10V (= 10,000 mV)

According to the equation  $\Rightarrow$  (10000 mV\* 2mV \* 0.1Kg)/(500Kg \* 4) = 1  $\geq$  0.2uV As the calculated value is greater than 0.2uV, this weight system design has no problem.

# 4. Weight Setup (Calibration) Mode

What is the weight setup?

It refers to the calibration to set the displayed value to the actual weight in displaying weights.

#### How to Access to the Weight Setup Mode

Turn on the power supply to access to the weight setup mode while pressing Cal S/W after removing the sealing. Press the setup key long in the weight setup mode to return to the weighing mode.

#### 4-1. Weight Setup Menu (CAL1 - CAL9)

- CAL 1: Maximum capacity
- CAL 2: Minimum division and decimal position setting
- CAL 3: Weight calibration
  - 3-1. Setting the range of multiple calibration
  - 3-2. Zero calibration
  - 3-3. Setting weight
  - 3-4. Span calibration
- CAL 7: Gravity adjustment
- CAL 8: Zero adjustment
- CAL 9: Factor calibration
- CAL 10: Setting dual range

#### $CAL\ 1\ (\text{CAL}\ 1\ \text{automatically starts.})$

Function: Setting Maximum Value Range of set value: 1 ~ 99,999			
Used key	Display	Descriptions	
:Save and next Menu navigation  O   TEM   ~ 90000000000000000000000000000000000	C= 10000	Max. value = 10000kg	
change CLEAR :End	C= 10	Max. value = 10kg	

Note 1. It means the maximum weight value to be weighed by the scale.

#### CAL 2

Function: Minimum division and decimal position setting Range of set value: 0.001 ~ 9999			
Used key	Display	Descriptions	
	d = 0.001	Minimum division 0.001 kg	
SET :Save and next Menu navigation  O TEM ~ 900000000000000000000000000000000000	d = 0.01	Minimum division 0.01 kg	
	d = 0.1	Minimum division 0.1 kg	
:Set decimal point	d= 1	Minimum division 1 kg	
and end	d= 10	Minimum division 10 kg	

- Note 1. To end CAL2, press key when a decimal point is set.
- Note 2. The minimum division means the value of a division.
- Note 3. Set the external resolution within 1/30,000 as the value by dividing the maximum weight by the minimum division.
  - If the external resolution is 1/30,000 or more, Err 21 is shown.
- Note 4. The position of a decimal point is decided by the position of a decimal point for the minimum division set in CAL2.
- Note 5. If the minimum division is set to any value out of 1, 2 and 5 unit, "ERR DIV" is shown.


#### 3 CAL

#### **CAL 3-1**

Function: Setting Multi Calibration Step Range of set value: 1 ~ 5			
Used key	Display	Descriptions	
SET :Save and next	STEP-1	Setting multi calibration for step 1 (CAL3-3 and CAL3-4 are carried out once)	
Menu navigation  O TEM  ~ 9 OCK  : Set value change	STEP-3	Setting multi calibration for step 3 (CAL3-3 and CAL 3-4 are carried out three times.)	
:End	STEP-5	Setting multi calibration for step 5 (CAL3-3 and CAL 3-4 are carried out five times.)	

st If the actual curve of load cell is a straight line, set the range of weight setup to 1.

<sup>\*</sup> A function to use, when the output of load cell is corrected by setting multiple points in some sections because the actual curve of load cell is not a straight line.



Zero and Span points to interpolate weight from Load Cell

#### **CAL 3-2**

Function: Zero Calibration			
	Used key	Display	Descriptions
SET	:Zeroing	UnLoAd	Empty the load tray and press the setup key.
CLEAR	:End	1234	The current weight value is displayed. Confirm 'Stable' and press the setup key.
			Zeroing in progress

Note 1. If zeroing finished with no error, it moves to Setting Weight (CAL 3-3) although no key is pressed.

Note 2. When zero point is too low, an error message "ERR27" is displayed.

Note 3. When zero point is too high, an error message "ERR26" is displayed.

#### **CAL 3-3**

Function: Setting Weight Range of set value: 1 ~ 99,999			
Used key	Display	Descriptions	
:Save and next Menu navigation	LOAD 1	It means the weight setting mode. (Number = multi calibration number)	
○ TEM ~ 9 BOOK : Set value change	W=100.00	100.00 (unit: Kg or Ton)	
:End	W= 0.10	0.10 (unit: Kg or Ton)	

Note 1. Set the weight within a range of  $10\% \sim 100\%$ .

Although 100% of the maximum weight is given as the initial value, enter the desired weight again if the weight is different from the initial value.

(If the weight exceeds the maximum weight, "ERR 23" is displayed.)

If the weight is 10% or less, "Err 20" is displayed and if the calibration is set to 10% or less, the accuracy is lowered.

#### **CAL 3-4**

Function: Weight Calibration)				
	Used key	Display	Descriptions	
SET	:Span adjustment	LoAd	Load the weight set in CAL 4-3 and press the setup key.	
CLEAR		12345	The current weight value is displayed. Confirm 'Stable' and press the setup key.	
CLAIT	:End		Span adjustment in progress	

Note 1. CAL 3-3 and CAL 3-4 are repeated as many as STEP is set in CAL 3-1.

At this time, the weight value should be set to a value greater than the previous one.

Note 2. Move to CAL-1 if the span adjustment is over with no error.

Note 3. When zero point is low, an error message "ERR24" is displayed.

Note 4. When zero point is high, an error message "ERR25" is displayed.

Note 5. After finishing calibration, press the setup key for 2 seconds or more to convert to the weighing mode.

#### CAL 7

Function: Gravity Adjustment				
Used key	Display	Descriptions		
:Save and next Menu navigation	G-CAL	It means you accessed to the menu for the gravity adjustment.		
O TEM ~ 9 BOOK: Set value change	Gr-CAL 9.XXXX	Set the gravity for the production place.		
:End	Gr-SET 9.XXXX	Set the gravity for the place to use the product.		

Note 1. If the gravity of the indicator production place is different from that of the place to use, the gravity adjustment can be done using this function.

#### CAL8

Function	Function: Zero adjustment - calibration when any zeroing error occurs.				
Used key		Display	Descriptions		
	:Zeroing	2-CAL	Empty the load tray and press the setup key.		
SET	:End	1234	The current weight value is displayed. Confirm 'Stable' and press the setup key.		
			Zero adjustment in progress		

Note 1. Use this function when zeroing is not passed for any shock to the load cell. The range of zero adjustment is  $0 \sim 2 mV/V$ .

Note 2. Move to CAL-1 if the zero adjustment is over with no error.

Note 3. When zero point is too low, an error message "Err27" is displayed.

Note 4. When zero point is too high, an error message "Err 26" is displayed.

#### CAL9

Function: Factor Calibration				
Used key	Display	Descriptions		
:Save and next Menu navigation	NOT USE	This function cannot be used because of multi calibration.		
O ITEM ~ 9 B-CHK : Set value change	FACtor	It means you entered the factor correction mode.		
:End	12345	The current factor is displayed.		

Note 1. As this is a menu to set the weight setup with no weight, general users have no need to use it.

Note 2. This can be used only when the range of multi calibration in CAL 4-1 is set to 1.

"NOT USE" is displayed when the range of CAL 4-1 is set to 2 or larger.

Note 3. Enter a password to enter the factor correction mode.

#### **CAL 10**

#### **CAL 10-1**

Function: Setting Dual Range Range of set value: 0 ~ 1				
Used key	Display	Descriptions		
:Save and next Menu navigation    O   TEM   ~   9   9   1   1   1   1   1   1   1   1	DUAL- 0	Dual range function is not used.		
CLEAR :End	DUAL-1	Dual range function is used.		

Note 1. If the resolution capability is 1/10,000 or higher, "OVER" message is displayed and return to the CAL menu mode.

#### **CAL 10-2**

Function: Setting the applied section for the Dual Range Range of set value: 0 ~ 99999				
Used key Display		Descriptions		
:Save and next Menu navigation	M 1000	Dual range is applied to less than 1000kg.		
O   TEM ~   9   Set value change	M 5000	Dual range is applied to less than 5,000kg.		
:End	M 10000	Dual range is applied to less than 10,000kg.		

Note 1. If the input value is greater than the maximum value, "ERR SET" message is displayed and returned to the CAL menu mode.


# 4-2. How to Seal the Indicator (Sealing)

After the calibration mode is carried out, proceed to the following step.

1. Tighten the CAL switch bolt.

2. Connect the sealing wire as shown in the picture.

3. Press the sealing wax as shown in the picture.



# 5. Set Mode


#### 5-1. How to Enter the Set Mode

Turn on the power while pressing key at the indicator front to start the Set Mode.

Or, Hold key for about 3 seconds to move from other mode to the convesion mode.

After finishing the setup in the Set Mode, press key for a long time

#### 5-2. Descriptions on key operations in the Set Mode



# 5-3. Set Menu Descriptions (F00 $\sim$ F99)

		. ,
		General Function
F01	-	Date Change
F02	-	Time Change
F03	(00)	Auto Power Off
F04	(10)	A/D Converting Speed
F05	(10)	Digital Filter
F06	(00)	Vibration Filter
F07	(02)	Motion Detection Condition
F08	(02)	Automatic Zero Tracking Compensation
F09	(00)	Weight Backup
F10	(00)	Set Hold Type
F12	(00)	Set Auto Hold Range
F13	(10)	Set Zero Range
F14	(01)	Set ZERO, TARE Keys Availability
F16	(00)	Set the Front Key Input to be Allowed
F17	(00)	Set "F1" Key
F18	(00)	Set "F2" Key
F19	(00)	Set Use Unit
F21	(10)	Set Initial Zero Range
F23	(09)	Set Excessive Weight Check
F24	(00)	Set Backlight Operational Condition (LCD)
F25	(03)	Set LED Brightness or Backlight Brightness

 $<sup>\</sup>boldsymbol{*}$  Note. Number in () is the default at the factory shipment.

RS-232 Serial Communication Function				
F26	(00)	Device ID		
F27	(00)	Parity Bit		
F28	(04)	COM1 Baud Rate		
F29	(00)	COMI Usage		
F30	(00)	COM1 Output Format		
F31	(00)	COM1 - Output Mode		
F32	(04)	COM2 Baud Rate		
F33	(01)	COM2 Usage		
F34	(00)	COM2 Output Format		
F35	(00)	COM2 - Output Mode		
Print Function				
F40	(02)	Set Printer in Use		
F41	(00)	Set Print Format		
F42	(00)	Automatic Print		
F43	(01)	Print Line Feed		
F44	-	User Print Message Input		
F45	(01)	Print Output		
F47	(01)	Data Initialization after Summation Print		
F48	(01)	Print Item Number		

Checker Function			
F50	F50 (00) Measurement Mode		
F51	F51 (00) Checker Buzzer On/Off		

Set Mode Initialization			
F90		Password Change	
F99	-	Set the Set value of Set Mode to the Factory Default	

 $<sup>\</sup>ensuremath{^{*}}$  Note. Number in () is the default at the factory shipment.

## 5-3-1. General Function

#### F01

Function	Date Change	
Numeric key	Display	Meaning
: assigning data	02.01.10	January 10, 2002

#### F02

Function	Time Change	
Numeric key	Display	Meaning
: assigning data	11.30.10	11 o'clock 30 minutes and 10 seconds AM

#### F03

Function	Auto Power OFF	
	Display	Meaning
Setting range	F03.00	Not used.
(00~30)	F03.10	Automatic power off after 10 minutes in the waiting mode.
	F03.30	Automatic power off after 30 minutes in the waiting mode.

Note 1. The power is automatically off if the defined time continues at the zero point after the automatic power off is set.

#### F04

Function	Setting A/D Converting Speed	
	Display	Meaning
Setting range	F04.10	10 rounds/second
(00~99)	F04.20	20 rounds/second
	F04.80	80 rounds/second

#### F05

Function	Setting digital filter	
	Display	Meaning
Setting range	F05.10	Display of average for No. 10
$(00 \sim 50)$	F05.30	Display of average for No. 30
	F05.50	Display of average for No. 50

#### F06

Function	Setting vibration filter	
	Display	Meaning
Setting range (00 ~ 99)	F06.00	Vibration filter OFF
	F06.10	Compensation for the vibration value of 5 divisions (0.5d * 10)
	F06.99	Compensation for the vibration value of 49.5 divisions (0.5d * 99)

Note 1. Apply this function to a place with heavy vibrations.

(The display response speed becomes slower when the vibration filter is applied.)

Note 2. This function should be adjusted appropriately to the site while the speed of weight variations in F04 is being lowered little by little.

#### F07


Function	Setting Motion Detection Condition	
	Display	Meaning
Setting range	F07. 1	The 'Stable' lamp is lit if the weight changes within 0.5 division.
(1~99)	F07. 2	The 'Stable' lamp is lit if the weight changes within 1 division.
	F07.10	The 'Stable' lamp is lit if the weight changes within 5 division.

#### F08

Function	Setting Automatic Zero Tracking Compensation	
	Display	Meaning
Setting range (0~9)	F08. 0	Automatic zero function is not used.
	F08. 1	If it changes slowly to 0.5 divisions or less, it is compensated.
	F08. 2	If it changes slowly to 1.0 divisions or less, it is compensated.
	F06. 9	If it changes slowly to 4.5 divisions or less, it is compensated.

Note 1. This function compensates zero automatically if the weight at the zero point does not exceed the division in a certain range within a specific time.

Ex) If F08 is set to "4" when the maximum displayed division is 120.0kg and the value of a division is set to 0.05kg;



#### F09

Function	Weight Backup Function	
Setting range (0, 1)	Display	Meaning
	F09. 0	Weight backup is not used.
	F09. 1	Weight backup is used.

Note 1. As the backup state memorizes the initial status at zero for the weighing machine even during the blackout or when the power is turned off, the weight value is displayed if there is any weighing object in the weighing machine when the power is turned on.

If the weighing tray is empty, press the "ZERO" key to memorize the zero again.

#### F10

Function	Set Hold Type	
	Display	Meaning
Setting range (0 ~ 3)	F10. 0	Ordinary hold: calculating the average of weights for shaking objects
	F10. 1	Peak hold: calculating the maximum value for shaking objects
	F10. 2	Sampling hold: calculating the sampling value for shaking objects
	F10. 3	Automatic hold: automatically calculating the average weight of
		shaking objects

Note 1. If any load more than 'Over' is applied or at the zero, the hold is automatically released. Note 2. Use automatic hold function, when you weight an animal or moving.

#### F12

Function	Auto Hold Range	
Setting range (0~99)	Display	Meaning
	F12. 09	Auto hold range is 9 division
	F12. 99	Auto hold range is 99 division

#### F13

Function	Set Zero Range	
	Display	Meaning
Setting range (0~99)	F13. 2	The 'Zero' Key is operated within 2% of the maximum weight.
	F13.10	The Zero' Key is operated within 10% of the maximum weight.
	F13.99	The 'Zero' Key is operated within 99% of the maximum weight.

Note. Be aware that the load cell can be damaged if you set the value to F13=10% or more.

#### F14

Function	ZERO and TARE Keys Availability	
Setting range (0, 1)	Display	Meaning
	F14. 0	Always operated.
	F14. 1	Operated when the weight is 'Stable'.

Function	Set the front key input to be allowed.	
a	Display	Meaning
Setting range (0~1)	F16. 0	The front keys are unlocked.
	F16. 1	The front keys are locked.

Note 1. If it is set to 1, some function keys among the front keys cannot be used.

(Print, Hold, Tare, Step, Subtotal, Grand total, Weighing count, Item number, Setup, etc)

#### F17

Function	Set the use of function	n key 1
Setting range	Display	Meaning
(0~15)	F17. XX	Set function key 1 to the key in the code table.

Note 1. Set the desired functions using <Table 1. Function Key Code>.

(LCD product = "11" and LED product = "0" as the default at the product shipment)

#### F18

Function	Set the use of function key 2	
Setting range	Display	Meaning
(0~15)	F18. XX	Set function key 2 to the key in the code table.

Note 1. Set the desired functions using <Table 1. Function Key Code>.

(LCD product = "12" and LED product = "0" as the default at the product shipment)

#### Table 1> Function Key Code Table

Function Name	Key Code	Function Name	Key Code
Empty	00	Hold	08
Zero Point	01	Battery	09
Gross Weight * Net Weight	02	Item Number	10
Tare	03	High Limit (LCD, SC Only)	11
Subtotal	04	Low Limit(LCD, SC Only)	12
Grand Total	05	Tare Lease	13
Weighing Count	06	Piece Weight Value (LCD Only)	15
Print	07		

#### F19

Function	Set the use of unit	
Cotting was	Display	Meaning
Setting range (0, 1)	F19. 0	The unit is set the 'kg'
(0, 1)	F19. 1	The unit is set the 'lb'

Function	Set the initial zero range	
	Display	Meaning
Setting range	F21.02	Set the initial zero up to 2% of the maximum weight
(02~20)	F21.10	Set the initial zero up to 10% of the maximum weight
	F21.20	Set the initial zero up to 20% of the maximum weight

Note 1. Please consult with an engineer because setting 10 or larger value might affect the load cell greatly.

#### F23

Function	Setting the range of check for the excessive weight (weighing unit)	
Setting range (00~99)	Display	Meaning
	F23 09	Excessive weight from the maximum weight +9 divisions
	F23.99	Excessive weight from the maximum weight +99 divisions

#### F24(CI-201A)

Function	Backlight Operation	
	Display	Meaning
	F24 0	Backlight off
Catting manage	F24 1	Backlight on when any key is operated.
Setting range (0~5)	F24 2	Backlight on when the weight changes.
(0~3)	F24 3	Backlight on when it is 'Stable' after the weight changes.
	F24 4	Backlight on when a key operates or the weight changes.
	F24 5	Backlight on all the time

Note. Although it is set to 5, press the power key shortly to turn off the backlight.

Function	Set Backlight and LED Brightness	
	Display	Meaning
	F25 1	Set 10% of brightness
	F25 2	Set 30% of brightness
Setting range	F25 3	Set 50% of brightness
(1~7)	F25 4	Set 60% of brightness
	F25 5	Set 70% of brightness
	F25 6	Set 90% of brightness
	F25 7	Set 100% of brightness

Note 1. Any value out of the setting range, the brightness will be set to '3'.

#### 5-3-2. RS-232 (Serial Communication) Function

#### F26

Function	Set Device ID	
Setting range (00 ~ 99)	Display	Meaning
	F26.00	Device ID 00
	F26.99	Device ID 99

Note 1. This function enables to use the unique indicator ID in the command mode.

#### F27

Function	Set Parity Bit – RS232C & PRT	
	Display	Meaning
Setting range	F27. 0	Data bit 8, stop bit 1, parity bit: none
(0~2)	F27. 1	Data bit 7, stop bit 1, parity bit: even number
	F27. 2	Data bit 7, stop bit 1, parity bit: odd number

Note 1. F26 and F27 apply commonly to 2 serial communications (RS23C and PRT).

#### Serial Communication COM1 Function

#### F28

Function	Set COM1 Baud Rate	
	Display	Meaning
	F28. 0	600 bps
	F28. 1	1200 bps
	F28. 2	2400 bps
Setting range	F28. 3	4800 bps
(0~8)	F28. 4	9600 bps
	F28. 5	19200 bps
	F28. 6	38400 bps
	F28. 7	57600 bps
	F28. 8	115200 bps

#### **F29**

Function	Set COM1 - Usage	
Cotting range	Display	Meaning
Setting range (0~1)	F29 0	Connect to a printer
(0~1)	F29 1	Connect to a computer or auxiliary display

<sup>\*</sup> If F29: 0 and F33: 0, "ERR-Set" is displayed with no print.

#### **F30**

Function	Set COM1 - Output Format				
	Display	Meaning			
Setting range	F30 0	22 bytes for CA			
(0~2)	F30 1	10 bytes for CA			
	F30 2	18 bytes for AND			

#### F31

Function	Set COM1 - Output Mode				
	Display	Meaning			
	F31 0	No data out			
	F31 1	Transmission for both the stable and instable time (stream mode)			
Setting range	F31 2	One time transmission after the weight is stabilized.			
(0~4)		Transmission only if data is requested.			
	F31 3	* Data request signal: device ID (F26) _ 1 byte communication			
		(Data on request: $1=0x01$ , $10=0x0A$ )			
	F31 4	Response to the data request - Command Mode			

Set the value of F31 to '1' or more if the print mode is used.

Note 1. Command Mode Table

		Dat	ta R	eques	t Sign	al of	CI-	200			Descriptions on	CI-200
0	1 2	3	4	5	6	7	8	9	10	11	Request Signal	Output Signal
D	dd	K	Z	CR	LF						Zero Point Key	Received Data Return
D	dd	K	T	CR	LF						Zero Point Key	Received Data Return
D	dd	K	G	CR	LF						Gross Weight Key	Received Data Return
D	dd	K	N	CR	LF						Net Weight Key	Received Data Return
D	dd	Н	D	CR	LF						Hold Key	Received Data Return
D	dd	K	В	CR	LF						Print Key	Received Data Return
D	dd	K	С	CR	LF						Total Print Key	Received Data Return
D	dd	K	W	CR	LF						Weight Data Request Signal	Received Data Return
D	dd	I	D	0	0	0	0	0	CR	LF	Device Number	Received Data Return
D	dd	Н	Y	0	0	0	0	0	CR	LF	Key Tare Value	Received Data Return
D	dd	Н	I	0	0	0	0	0	CR	LF	High Limit(LCD Only)	Received Data Return
D	dd	Н	L	0	0	0	0	0	CR	LF	Low Limit (LCD Only)	Received Data Return

Note 1. (D: 0x44, dd:00-99, K:0x4B , Z:0x5A , CR: 0x0D, LF: 0x0A)  $\frac{1}{2} \text{ dd} = \text{Device Number (2byte), CR} = 0x0D, LF: 0x0A}$  Ex) If a device number is 10, dd becomes 0x31 and 0x30.

Ex) If you want to operate the zero point key when a device number is 11, the indicator operates zeroing if the hex code of "44 31 31 4B 5A 0D 0A" is sent.

#### Note 1. NT-200 Command Mode Table

Command (ASCII Code)	Description	Status	
Н	High Limit	Read/Write	
LO	Low Limit	SC	Read/Write
KT	Key Tare Value		Read/Write
CO	Code		Read/Write
WT	Current Weight	Read	
ZE	Operation with ZERO Key	Read	
TR	Operation with TARE Key	Read	
GN	Operation with Gross/Net K	Read	
ID	Device Number (ID) Chang	Read	
HD	Operation with HOLD Key	Read	
PR	Operation with PRINT Key	Read	
TP	Operation with Total Print K	Read	
PW	POWER OFF		Read

#### Read

1	2	3	4	5
Device ID	Command		CR	LF

Note 1. Device ID is hex value and Command is ASCII value. [Ex] If Device ID is 13, a user wants to know the current weight value -> 0x0d 0x57 0x54 0x0d 0x0a

#### Write

1	2	3	4	5	6	7	8	9	10
Device ID	Com	mand	D.	ATA (No	t include d	ecimal poi	nt)	CR	LF

#### Format for Device ID Change

1	2	3	4	5	6
Device ID	Command		DATA	CR	LF

Note 2. When you change code and device number, the data value is  $\ensuremath{\mathsf{HEX}}$  1 byte.

#### Serial Communication COM2 Function

#### F32

Function	Set COM2 Baud Rat	te
	Display	Meaning
	F32 0	600 bps
	F32 1	1200 bps
	F32 2	2400 bps
Setting range	F32 3	4800 bps
(0~8)	F32 4	9600 bps
	F32 5	19200 bps
	F32 6	38400 bps
	F32 7	57600 bps
	F32 8	115200 bps

#### F33

Function	Set COM2 - Usage	
Catting maga	Display	Meaning
Setting range	F33 0	Connect to a printer
(0~1)	F33 1	Connect to a computer or auxiliary display

#### F34

Function	Set COM2 - Output Format			
	Display	Meaning		
Setting range	F34 0	22 bytes for CA		
$(0 \sim 2)$	F34 1	10 bytes for CA		
	F34 2	18 bytes for AND		

#### F35

Function	Set COM2 - Output Mode			
	Display	Meaning		
Setting range	F35 0	No data out		
$(0 \sim 2)$	F35 1	Transmission for both the stable and instable time (stream mode)		
	F35 2	One time transmission after the weight is stabilized.		

Set the value of F35 to '1' or more if the print mode is used.

<sup>\*</sup> If F29: 0 and F33: 0, "ERR-Set" is displayed with no print.

\* COM1 and COM2 cannot be used together as the printer function.

#### 5-3-3. Print Function

#### F40

Function	Set a printer to use	
	Display	Meaning
Setting range	F40 0	Not used.
(0~2)	F40 1	DLP (Label Printer)
	F40 2	DEP (Roll Printer)

#### F41

Function	Set print format	
	Display	Meaning
Setting range	F41 0	Set print format 0
(0~2)	F41 1	Set print format 1
	F41 2	Set print format 2

#### F42

Function	Set automatic print	
Cotting maga	Display	Meaning
Setting range	F42 0	Manual print
(0, 1)	F42 1	Automatic print

Note 1. If the automatic print is set, print can be done with no press of print key when the weight is stable.

#### F43

Function	Set Line Feed	
Cotting maga	Display	Meaning
Setting range (0~9)	F43 1	1 Line feed
(0~9)	F43 9	9 Line feed

#### [ Print Format 0 ]

Date, Time, Weighing No. (Item No.), Net Weight Weight

2002. 1. 1	12:30
0001 ID_01:	50.0 kg
0002 ID_01:	100.0 kg
0003 ID_01:	200.5 kg
	-

#### [ Print Format 1 ]

Date, Time, Weighing No. (Item No.), Net

2002. 1. 1	12:30
0001 ID 01:	50.0 kg
2002. 1. 1	12:40
0002 ID 01:	50.0 kg
2002. 1. 1	12:50
0003 ID 01:	50.0 kg
000512_01.	30.0 Kg

#### [ Print Format 2 ]

Date, Time, Weighing No. (Item No.), Net Weight

2002. 1. 112:30 No.0001 ID\_01 1000.0 kg 0.0 kg Gross: Tare : 1000.0 kg Net 2002. 1. 112:40 No.0002 ID\_01 2000.0 kg 500.0 kg Gross: Tare : 1500.0 kg Net

Note 1. If the power is turned off and then on, the number and total are initialized to 0001.

Note 2. The output of item number (ID\_XX) depends on the setting in "F48". Note 3. The possible number for print is a range of 1~9999.

#### [ Total Print Format ]

Total Format			
ID_0	1 TOTAL		
2004.06.24	14:32:54		
COUNT	22		
WEIGHT	4500.05kg		
GRAN	GRAND TOTAL		
2004.06.24	14:32:58		
COUNT	123		
WEIGHT	12500.10kg		

Note 1. When a label printer (DLP-50) is used, the subtotal and grand total functions are not supported and Err-12 is displayed.

Note 2. After summation, data are maintained or initialized depending on the set value in F47.

#### ☐ CAS DLP Protocol

Variable	Descriptions	
V00	Gross Weight (8 bytes)	
V01	Tare (8 bytes)	
V02	Net Weight (8 bytes)	
V03	Barcode (Net Weight) (8 bytes)	
V04	Count in the Count Mode (8 bytes)	
V05	Percent in the Percent Mode (8 bytes)	

The weight, count and percent cannot be printed at the same time. Values that can be accurately printed are those for [weight, count and percent].

#### ☐ User's Output Message Protocol

Command (ASCII code)	Descriptions	Status
UM	User output message	Write

The maximum length is 40 bytes. 0xFF should be put in the last byte. 20 bytes are printed in a line and the message starts from the upper left corner.

#### F44

Function	Enter the user output message	
	Display	Meaning
Set Range (32 ~ 255)	12-065	Designate a character "A" equivalent to ASCII code 65 in the 12th data
	00-032	To print out the added contents, designate ASCII code 32 to 0th data.
	18-255	The end has to be meant by designating ASCII code 255 next to the last data.



: set number, | CLEAR | : coordinate increase, | SET | : end entry



(If a coordinate increase is done when the input range exceed a range of 32 ~ 255, it will be cleared with "255")

- Note 1. This function adds something to write down on the print format. (Ex: company name, Phone number)
- Note 2. Coordinates that can be designated have a range from 0 to 71, of which 0th data designates whether or not to print the added contents (032: printed, others: not printed). Accordingly, the actually printed contents will include contents from 1st data to the part right before the coordinate where data 255 is assigned.
- Note 3. If you want to add the company name "CAS" to the existing print format, you might assign as

P00-032 (ASCII code 32: data starts),

P01-067 (ASCII code 67: character C)

P02-065 (ASCII code 65: character A)

P03-083 (ASCII code 83: character S)

P04-255 (ASCII code 255: data ends)

#### F45

Function	Set print output	
Setting range (0, 1)	Display	Meaning
	F45 0	Print on both the stable and instable time
	F45 1	Print when the weight is stable.

#### F47

Function	Initialize data after the summation is printed.	
Catting man	Display	Meaning
Setting range	F45 0	Maintain the status
(0, 1)	F45 1	Initialize data after the summation is printed.

#### F48

Function	Setting print item number		
Cotting maga	Display	Meaning	
Setting range (0, 1)	F45 0	Not printing item number on print output	
(0, 1)	F45 1	Printing item number on print output	

#### 5-3-4. Checker Function

F50

Function	Select the weighing mode (LCD, SC Only)		
	Display	Meaning	
Setting range F50 0		Not used.	
(0~2)	F50 1	Use as the checker mode	
	F50 2	Use as the limit mode	

#### [CHECKER MODE]

Weight Comm Signal	(Low Limit) (High Limit) 0 kg 50 kg 100 kg	OUT PUT
LOW		1 0
HIGH		1 0
OK		1 0

Note 1. All the outputs are generated regardless of the stable status.

#### [LIMIT MODE]

Weight Comm Signal	(Low Limit) (High Limit) 0 kg 50 kg 100 kg	OUT PUT
LOW		1 0
HIGH		1 0
ОК		1 0

Note 1. OK signal is displayed only for the stable status.

Function	Set Buzzer On/Off on the Checker Function (LCD, SC Only)		
Catting	Display	Meaning	
Setting range (0, 1)	F51 0	General functions are operated as the buzzer.	
(0, 1)	F51 1	Buzzer ON when the checker function is OK.	

#### 5-3-5. Other Functions

#### F90

Function	Password Change		
Setting range	Display	Meaning	
(0, 1)	F98. 0	Password not changed.	
(0, 1)	F98. 1	Password Changed	
		Enter the current password using numeric keys.	
	Good	Erher the current password using numeric keys.	
Password		Enter a new password.	
Change	PASS	Effici a new password.	
		Enter the new password again.	
	Change	Earled the new password again.	

#### F99

Function	Set default	
Satting manage	Display	Meaning
Setting range	0	No initialization functions for indicator.
(0, 1)	1	Carry out the initialization functions for indicator.

Note 1. To set values to the same as the factory default for the indicator, press the setup key after setting F99 to 1.

#### 6. Test Mode

#### 6-1. How to Enter the Test Mode

Test mode starts when the power is turned on while pressing key in the front of the indicator.

Press the number for the test menu as you wish.

To enter the weighing mode during test, press key for a long time.

#### 6-2. Test Menu (TEST 1 - TEST10)

Test 1: Key test

Test 2: Display test

Test 3: Load cell test and A/D conversion test

Test 4: RS-232 serial communication test (COM1, COM2)

Test 5: Printer test

Test 8: EEPROM test

Test 9: Battery test

Test 10: Clock (RTC) test

#### Test 1

Function: Key test				
Used key	Display	Descriptions		
: Higher Menu Other keys: Test	1 1	When you press any key to test, the number and code for the key are displayed on the screen.		

<Key List>

Key	Number	Code	Key	Number	Code	Key	Number	Code
1 ZERO	1	1	<b>6</b> w-схт	6	6	O ITEM	0	0
2 g/N	2	2	7 <sub>PRINT</sub>	7	7	SET	70	30
3 TARE	3	3	8 HOLD	8	8	F1	28	28
4 i-sum	4	4	9 B+CHK	9	9	F2	29	29
5 0-SIM	5	5	CLEAR	11	27			

#### Test 2

Function: Display Screen Test				
Used key	Display Descriptions			
: Higher Menu Other keys: Test	○ *O* NET SUM HOLD LO OK HI E DGS  □ □ □ □ □ □ □ □ □ □ □ □ □ □ □ □ □ □ □	An LCD lamp is on.		
	8.8.8.8.8.	An LED lamp is on.		

Test 3

Function: Load cell test and A/D conversion test				
Used key	Display	Descriptions		
SET : Higher Menu	XXXXXX X.XX	The internal value for the current weight value is displayed. The output value of the current load cell is displayed in mv/V.		

Note 1. If key is pressed, the internal value of the current weight and the output of load cell (mv/V) are displayed repeatedly.

Note 2. Check this number to see if it moves well, while loading or unloading a weight to the load tray. If the number is fixed or "0" is displayed, check the connection of load cell once again.

Test 4

Function: Serial Communication Test						
Used key	Display	Descriptions				
: Higher Menu Other keys: Test	Tx Rx	Status to wait for transmission or				
		reception				
	05 13	Transmission: 5, Reception: 13				

Note 1. Run this test while the communication program in the computer (ex: Hyper Terminal) is executing after connecting a serial port in the computer to the serial port on the back.

Note 2. Send '1' from the computer keyboard, check whether or not '1' is received properly on the indicator's screen, and then check whether or not '1' is received properly on the computer after pressing '1' from the indicator's keyboard.

#### TEST 5

Function: Printer Test				
Used key	Display	Descriptions		
: Higher Menu Other keys: Test	Print	No abnormality in the printer. Check the connection of the printer connector		

Note 1. Designate a printer used in the Set Mode (F30) in advance.

Note 2. If the printer connection and the designation are done correctly, the following details will be shown in the printer.

CAS Corporation Come And Succeed TEL 1577-5578 TEST OK

#### TEST 8

Function: EEPROM Test					
Used key Display Descriptions					
SET : Higher Menu	ROM OK	Displaying the status of EEPROM operation			

Test 9

Function: Battery test					
Used key	Display	Descriptions			
SET : Higher Menu	b 6.15	Displaying the current voltage of battery (6.15V)			

Test 10

Function: RTC Test					
Used key Display Descriptions					
SET : Higher Menu	SEC XX	XX : Displaying the progress of seconds (SEC)			

Note 1. If clear key is pressed, the current second changes to '0'.



#### 7-1. How to Enter the System Mode

Step	Display Screen and Key Input	Load Tray	Descriptio ns
1	Press key for about 3 seconds in the weighing mode.	Empty	
2	Screen display: "1. PCS" characters are blinking after "SYSTEM" is displayed.		
3	If the key is pressed, "1. PCS" characters are blinking.  If the key is pressed, "2. PER" characters are blinking.  If the key is pressed, "2. PER" characters are blinking.  If the key is pressed, "3. WGT" characters are blinking.		Select the mode to which you want to move.
4	If set key is pressed, the selected mode is set.		

Weighing Mode (I)				
Initial Screen	Descriptions			
0.0001	Weighing Mode			

Counting Mode (II)				
Initial Sci	reen	Descriptions		
0 ->0<-	0 PCS	Counting Mode		

Percent Mode (III)				
Initial S	creen	Descriptions		
0 ->0<-		Downst Mada		
	0.0%	Percent Mode		

#### 7-2. PCS MODE

#### 7-2-1. PCS MODE Sample Input Method (LCD Only)

Step	Display Screen and Key Input	Load Tray	Descriptions
1	Press key for about 3 seconds in the PCS Mode.	Empty	
2	Screen display: "1.SAMPL" characters are blinking.		
3	If ZERO key is pressed, "1. SAMPL" characters are blinking.  If ZG GN key is pressed, "2. WEIGH" characters are blinking.		Select the input method as desired.
4	Press Tzero keys.		
5	Screen display: A/D value is displayed after "SAMPLE" -> "LoAd" is shown.  (Wait until the weight is stable.)	Sample	Put samples on the load tray
6	Press key	Sample	Save sample weight
7	Screen display: "SUCCES" -> "NUMBER" is displayed.	Sample	
8	Enter the number of samples using \$\frac{1\frac{7\text{Eno}}{2\text{Eno}}}{2\text{keys}}\$, and then press key.  (Ex) If 10kg (sample) and 10 pieces, then the unit weight becomes 1kg.	Sample	
9	Screen display: It moves to PCS Mode after displaying "End".	Sample	

Note 1. The current weight is displayed when MODE". key is pressed during operating "1. PCS MODE".

Note 2. If the value of 1 PCS is smaller than 0.7 divisions of maximum resolution capacity when the number of samples is entered, Err-21 is displayed.

#### 7-2-2. PCS Mode Direct Input Method (LCD Only)

Step	Display Screen and Key Input	Load Tray	Descriptions
1	Press key for about 3 seconds in the PCS Mode.	Empty	
2	Screen display: "1.SAMPL" characters are blinking.		
3	If zeo key is pressed, "1. SAMPL" characters are blinking.  2 on key is pressed, "2. WEIGH" characters are blinking.		Select the input method as desired.
4	Press 2 GN + SET keys.		
5	Screen display: After "WEIGHT" is displayed, "0.000 KG" is displayed.		Weight input mode
6	Enter the weight of PCS using 12ERO keys, and then press key.		Save sample weight
7	Screen display: It moves to PCS Mode after displaying "End".		

Note 1. If set key is pressed during operations in the PCS MODE, it shows the current weight for 3 seconds and then returns to the PCS MODE.

Note 2. If the value of Piece Weight to a function key (F17 or F18), you may confirm the unit weight of 1 PCS.

#### 7-3. PERCENT MODE

#### 7-3-1. Percent Mode Sample Input Method (LCD Only)

Step	Display Screen and Key Input	Load Tray	Descriptions
1	Press 4 saw key for about 3 seconds in the Percent Mode.	Empty	
2	Screen display: "1.SAMPL" characters are blinking.		
3	If two key is pressed, "1. SAMPL" characters are blinking.  2 GN key is pressed, "2. WEIGH" characters are blinking.		Select the input method as desired.
4	Press 1 zen keys.		
5	Screen display: A/D value is displayed after "SAMPLE" -> "LoAd" is shown.  (Wait until the weight is stable.)	Sample	Put samples on the load tray
6	Press key	Sample	Save sample weight
7	Screen display: "SUCCES" -> "NUMBER" is displayed.	Sample	
8	Enter the number of samples using 1 ZERO Keys, and then press key.  (Ex) If 10kg (sample) and 10 pieces, then the unit weight becomes 1kg.	Sample	
9	Screen display: It moves to Percent Mode after displaying "End".	Sample	

Note 1. The current weight is displayed when key is pressed during operating in the

Percent Mode.

Note 2. If the value of 1 PCS is smaller than 0.7 divisions of maximum resolution capacity when the number of samples is entered, Err-21 is displayed.

#### 7-3-2. Percent Mode Direct Input Method (LCD Only)

Step	Display Screen and Key Input	Load Tray	Descriptions
1	Press key for about 3 seconds in the PCS Mode.	Empty	
2	Screen display: "1.SAMPL" characters are blinking.		
3	If the key is pressed, "1. SAMPL" characters are blinking.  2 GM key is pressed, "2. WEIGH" characters are blinking.		Select the input method as desired.
4	Press 2 GN + SET keys.		
5	Screen display: After "WEIGHT" is displayed, "0.000 KG" is displayed.		Weight input mode
6	Enter the weight of 100% using 1 ZERO Reys, and then press key.		Save sample weight
7	Screen display: It moves to Percent Mode after displaying "End".		

Note 1. If key is pressed during operations in the Percent MODE, it shows the current weight for 3 seconds and then returns to the PCS Mode.

Note 2. If the value of Piece Weight to a function key (F17 or F18), you may confirm the unit

weight of 1 PCS.

#### 8. General Function Descriptions

## 8-1. Item Number (Unique Number of Weighing Item: ID) Input Method

Step	Display Screen and Key Input	Load Tray	Descriptions
1	Press Key Screen display: "ID = XX"		"Meaning the value of the current item number"
2	Enter a desired ID using number keys		Input ID(=10)
3	Press key to save and exit	Item	An item number is registered. The weight is displayed.

Note 1. Product ID has a range of  $0 \sim 19$ .

#### 8-2. Key Tare Input Method

Step	Display Screen and Key Input	Load Tray	Descriptions
1	Press SET + 3 TARE keys	Empty	
2	Screen display: "t = 0.000	Empty	"Meaning the value of the current item number"
3	Enter a desired ID using number keys		
7	Press key to save and exit		

Note 1. If the remainder occurs when the input value is divided by the minimum unit, it is rounded and entered.

#### 8-3. How to Check Subtotal, Total and Weighing Count

Key	Descriptions
4 I+SUM	The current subtotal (partial summation) is displayed.
<b>5</b> G+SUM	The current total (entire summation) is displayed.
4 i-sum + 7 PRINT	The current subtotal (partial summation) is printed.  Subtotal is erased after it is printed.
5g-SUM + 7PRINT	The current total (entire summation) is printed.  Total is erased after it is printed.
6w-cnt	The current weighing count is displayed.

Note 1. While printing subtotal and total, an error (Err 12) is displayed with no connection to printer, and total and weighing count are erased.

1% unit of weight can be confirmed.

#### 8-4. How to Enter High Limit (LCD, SC Only)

Step	Display Screen and Key Input	Load Tray	Descriptions
1	Press key. Screen display: "H 0.000"		It means the current high limit.
2	Enter a desired value  1 ZERO USING Weys.		Change the high limit
3	Press key to save and exit.	Item	The weight is displayed after the high limit is saved.

Note 1. If the remainder occurs when the input value is divided into the minimum unit, the value is rounded and entered.

#### 8-5. How to Enter Low Limit (LCD, SC Only)

Step	Display Screen and Key Input		Descriptions
1	Press key. Screen display: "L 0.000"		It means the current low limit.
2	Enter a desired value  1 ZERO USING Weys.		Change the low limit.
3	Press key to save and exit.	Item	The weight is displayed after the low limit is saved.

- Note 1. If the remainder occurs when the input value is divided into the minimum unit, the value is rounded and entered.
- Note 2. If the key code value of F17 and 18 was changed from the initial value, the key code should be set again.
  - \* F1 key's basic value is set to the high limit.
  - \* F2 key's basic value is set to the low limit.
  - \* If the weight is greater than the high limit, the "HI" lamp appears on the screen. If the weight is smaller than the low limit, the "LO" lamp appears on the screen. If the weight is smaller than the low limit, the "LO" lamp appears on the screen.

#### 9. Weighing Mode

#### 9-1. Zeroing Function (used when the zero point changes) - LED


■ Range of zero point: within a range set in F13



#### 9-2. Tare Function (used for weighing with a container) - LED

#### ■ Maximum tare set range: maximum weight

\* Caution: the weight including the tare cannot exceed the maximum weight.



■ If you want to know the total weight;



Press the 'total \* net weight' key (the value of object's weight + tare is displayed.)

■ If you want to know the net weight;



Press the 'total \* net weight' key (the value of object's weight is displayed.) Remove the container and object from the load tray to display the saved tare.


■ If the tare is removed;



Remove the container and object from the load tray, and press the tare key (picture on the right) if the saved tare is only displayed (picture on the left).

#### 9-3. Hold Function (used for weighing moving objects) - LED

■ Ordinary Hold Function (hold function is performed when the hold key is pressed.)






The hold weight is displayed.

g It returns to the normal status and the hold lamp is turned off if you empty the load tray or press the hold key to release the held weight value.

 $\blacksquare$  Automatic hold function (the hold function is performed by automatically calculating the maximum weight of moving objects.)



- It returns to the normal status and the hold lamp is turned off if you empty the load tray or press the hold key to release the held weight value.
- \* Note. The hold function carries out operations according to the set value of F10.

#### 9-4. Zeroing Function (used when the zero point changes) - LCD

■ Range of zero point: within a range set in F13



Zero chanced.



Press Zero Key to set the zero lamp on and 0.

#### 9-5. Tare Function (used for weighing with a container) - LCD

■ Maximum tare set range: maximum weight

\* Caution: the weight including the tare cannot exceed the maximum weight.



O NET III kg



Put a container on the load tray. (Container weight: 10kg)

Press the tare key. (Tare is saved.)

Put an object on the load tray. (Net weight: 20kg)

■ If you want to know the total weight;



Press the 'total \* net weight' key (the value of object's weight + tare is displayed.)

■ If you want to know the net weight;



Press the 'total \* net weight' key (the value of object's weight is displayed.)
Remove the container and object from the load tray to display the saved tare.

■ If the tare is removed;



3 TARE



Remove the container and object from the load tray, and press the tare key (picture on the right) if the saved tare is only displayed (picture on the left).

### 9-6. Hold Function (used for weighing moving objects) - LCD

■ Ordinary Hold Function (hold function is performed when the hold key is pressed.)







Put an object on the load tray.

Press the hold key. Hold message is The hold weight is calculated displayed for a second.

for about 3~5 seconds.



The hold weight is displayed.

It returns to the normal status and the hold lamp is turned off if you empty the load tray or press the hold key to release the held

■ Automatic hold function (the hold function is performed by automatically calculating the maximum weight of moving objects.)







Empty the load tray.

The weight on the load tray is displayed.

The maximum value is displayed with 'HOLD'.

- It returns to the normal status and the hold lamp is turned off if you empty the load tray or press the hold key to release the held weight value.
- \* Note. The hold function carries out operations according to the set value of F10.

#### 10. Charge and Use Time

- $\blacksquare$  Charge the battery sufficiently when you use the product after storing it for a long time.
- $\blacksquare$  During the use of device,  $\square$  sign is shown (LCD) or 'LOW BAT' sign (LED) on the upper right corner, and then the power is turned off after a specific time.

When the power supply of battery reaches 5.6V, the battery alert lamp is turned on. When it reaches 5.2V, the power is automatically turned off.

■ When the battery alert lamp is turned on, charge the battery.

#### 10-1. How to Use and Charge the Chargeable Battery

■ When an adapter is connected, a red light in the power supply lamp and another red light in the charge lamp are turned on.

When the charging is completed, a green light in the charge lamp is turned on.

- The charging takes about 12 hours.
- $\blacksquare$  The complete charge mark is turned on if an adaptor is connected with no battery.

#### 10-2. Use Time of the Battery

	Condition	Use Time
CI-200A CI-200S	-	About 30 hours
C-I201A(LCD)	Backlight OFF	About 180 hours
C IZOTA(IZED)	Backlight ON	About 33 hours
CI-200SC	-	About 26 hours


<sup>%</sup> Note. The time stated above is subject to change depending on the period of battery use and the number of batteries.

To use the battery for a longer time, adjust the automatic power switch function in F03 and the brightness of display in F25.


#### 11. RS-232C Interface in Detail

#### 11.1. RS-232C Port Connection

(1) COM1 - RXD: Pin No. 2, TXD: Pin No. 3, GND: Pin No. 7



(2) COM2 - RXD: Pin No. 2, TXD: Pin No. 3, GND: Pin No. 7 (Option)



#### 11-2. How to Connect Serial Communication Devices

#### 11-2-1. How to Connect an Auxiliary Display

	TXD	3 O		O 3 Receive Data	
	GND	7 O		O 7 Signal Ground	
9 pin port (male)		male)	9	pin port (male)	
RS-232C port of CI-200				Serial port of an auxiliary display	

#### 11-2-2. How to Connect a Label Printer (DLP)

RXD 2O		O 3 Transmit Data
TXD 3O		O 2 Receive Data
GND 7 O		O 5 Signal Ground
9 pin port (male)	9	pin port (male)
RS-232C port of CI-200	Serial po	ort of DLP printer

Note. Refer to page 38 (Set Mode) for RS-232C communication and setting method.

#### 11-3. RS-232 Communication Protocol

#### 11-3-1. 22 Bytes for CAS

- (1) Data bit: 8, Stop bit: 1, Parity bit: none
- (2) Code: ASCII
- (3) Set the time to send data to the computer in the Set Mode.
  - Send all the time: if F30 and F35 are set to 1.
  - Send when the weight is stable: if F30 and F35 are set to 2.
  - Send upon data request: if F30 and F35 are set to 3.
  - Only if the computer send 1 byte of the indicator's device ID to the indicator, the indicator makes the defined output format.





US (Unstable) GS (Gross weight) Device ID Lamp Status byte

Empty Unit (kg/t) ST (Stable) NT (Net weight)

OL (Overload)

- $\blacksquare$  Device ID: Send ing 1 byte of device ID to selectively receive the information from the indicator to the receiver. (Device ID is set in F26.)
- $\blacksquare \ \, \text{Data (8 bytes): When the weight date including a decimal, for example, } 13.5\,\text{kg, 8 bytes of ASCII code corresponding to } 0', '0', '0', '0', '0', '1', '3', '.' and '5' are sent.$

#### ■ Lamp Status Byte

Bt7	Bt6 Stable	Bt5 0	Bt4 Hold	Bt3 Printer	Bt2 Gross Weight	Bt1 Tare	Bt0 Zero Point
-----	---------------	----------	-------------	----------------	------------------------	-------------	-------------------


#### 11-3-2. 10 Bytes for CAS

- (1) Data bit: 8, Stop bit: 1, Parity bit: none
- (2) Code: ASCII
- (3) Transmission data format: (10 bytes)

Data (8 bytes)	CR	IF
Data (O'O'yte3)	CIC	14

#### 11-3-3. 18 Bytes for AND

- (1) Data bit: 7, Stop bit: 1, Parity bit: odd number/even number
- (2) Code: ASCII
- (3) Transmission data format (18 bytes)



#### RS-422 & 485 Serial Communications (COM2)

RS-422 & 485 transmit signals with the voltage difference, which are more stable for electric noises than other communication methods.

In addition, the AC Power Cable or other electric wires should be placed separately, and the shield cable (0.5 $\Phi$  or more) dedicated to communications should be applied.

The recommended use distance is within 1.2km.


#### ▶ Setting output method

The same as RC232C before


#### ▶ Signal Format and Data Format

The same as RC232C before

#### - 422 Connection Diagram -



#### - 485 Connection Diagram -



Note. RS-422 & 485 communication is optional specifications, which are supported through COM2. Refer to page 42 (Set Mode) for the setup.

# 12. Error Message 12-1. Error Message from the Weight Setup Mode

Error	Cause	Solution
Err 20	The resolution was set in excess of the tolerance 1/10,000.	Lower the resolution.  As the resolution = maximum tolerance / value of one division, adjust the resolution to 1/10,000 or less by correcting either the maximum allowable weight in CAL 1 or the value of one division in CAL3 in the weight setup mode.
Err 21	The resolution was set in excess of the tolerance 1/30,000.	Lower the resolution.  As the resolution = maximum tolerance / value of one division, adjust the resolution to 1/30,000 or less by correcting either the maximum allowable weight in CAL1 or the value of one division in CAL3 in the weight setup mode.
Err 22	The weight for the span adjustment was set to less than 10% of the maximum capacity.	Set the weight to 10% or more of the maximum capacity (set in CAL1) from CAL4 in the weight setup mode.
Err 23	The weight for the span adjustment was set to more than 100% of the maximum capacity.	Set the weight within the maximum capacity (set in CAL 1) from CAL 4 in the weight setup mode.
Err 24	Too low span.	Set the weight again by lowering the resolution as the setting of the current resolution is not possible because of either abnormality or lower output in the load cell.  Two low weight for PCS and percent sample.
Err 25	Too high span.	There is either any abnormality or too high output in the load cell. Execute steps from the zeroing step in CAL4 in the weight set up again. Two high weight for PCS and percent sample.
Err 26	Too high zero point.	Check whether or not the load tray is empty.  Retry the weight setup after check at the test mode 3.
Err 27	Too low zero point.	Set the weight setting again after confirming what force is given to the load tray of the scale in the test mode 3.
Err 28	Weight is shaking.	Check the connection of the load cell connector.



#### 12-2. Error Message from the Weighing Mode

Error	Cause	Solution
Error	Cause	Solution
Err 01	The initialization of the scale cannot be done because of the shaking weight.	Turn on the power after placing the scale at a flat place with no vibration.
Err 02	Either the connection of load cell is wrong or there is abnormality in the A/D conversion section.	Check the connection between the load tray and the body.
Err 05	Either you are pressing a key for a long time or there is abnormality in the key section.	Make an inquiry to A/S.
Err 08	The zero key, tare key and start key were disabled at the instable weight.	Set the zero key, tare key and start key to the proper user conditions at F14 in the Set Mode.
Err 09	The current weight is out of the range of zero point.	Set the range of operations for the zero key to within 2% or 10% at F13 in the Set Mode.
Err 10	The tare to set is out of the maximum weight of the scale.	Set the tare to less than the maximum weight.
Err 12	The type of the configured printer is one that cannot support the total print.	DLP printers cannot make the total print. Set "F40" to '2' when DEP printers are used.
Err 13	The set value of zero point on the weight setting is out of range.	Check the status of the load tray and set the weight again.
Err 15	The range exceeded during setting the item code in the command mode.	Check the range of item code.
Err 82	There is abnormalities in the A/D set section.	Make an inquiry to A/S.
Over	The current weight on the load tray is too heavy and out of the allowable tolerance.	Avoid any weight in excess of the maximum allowable limit on the scale.  If the load cell is damaged, it should be replaced.

#### $\square$ Descriptions on Abbreviation on the Display

Abbreviation	Descriptions	Abbreviation	Descriptions	
"LOCK"	Key Lock	"UnLoad"	Unload the load tray	
"PASS"	Enter Password	"LoAd"	Load a weight	
"Discord"	Re-enter Password	"Good"	Successful Execution	
""CAL	Weight Set Mode	"SyS"	System Mode	
"SET"	Set Mode	"PCS"	PCS Mode	
"TEST"	Test Mode	"Per"	Percent Mode	
"OUEr"	Exceeding Maximum Load			

#### Appendix 1. ASCII Code Table

Character	Code										
Space	32	0	48	@	64	P	80	`	96	p	112
!	33	1	49	Α	65	Q	81	a	97	q	113
"	34	2	50	В	66	R	82	b	98	r	114
#	35	3	51	C	67	S	83	с	99	s	115
\$	36	4	52	D	68	T	84	d	100	t	116
%	37	5	53	Е	69	U	85	e	101	u	117
&	38	6	54	F	70	V	86	f	102	v	118
•	39	7	55	G	71	W	87	g	103	w	119
(	40	8	56	Н	72	X	88	h	104	X	120
)	41	9	57	I	73	Y	89	i	105	у	121
*	42	:	58	J	74	Z	90	j	106	Z	122
+	43	;	59	K	75	]	91	k	107	{	123
,	44	<	60	L	76	\	92	1	108	ı	124
-	45	=	61	M	77	]	93	m	109	}	125
	46	>	62	N	78	^	94	n	110	~	126
/	47	?	63	О	79	_	95	О	111	End	0

# MEMO

#### **MEMO**



#### **MEMO**

82







CAS BLDG., # 440-1, SUNGNAE-DONG, GANGDONG-GU, SEOUL, KOREA TEL\_ 82 2 2225 3500 FAX\_ 82 2 475 4668 www.globalcas.com

Specifications are subject to change for improvement without prior notice.

9007-133-0033-3 2010.05